



**DZ**

**Drainage Pumps**



**Installation &  
Operating Manual**




# INDEX

<b>1. PUMP SPECIFICATIONS</b>	1
<b>2. INSTALLATION</b>	3
<b>3. ELECTRICAL CONNECTIONS</b>	3
<b>4. PRIMING</b>	3
<b>5. OPERATING &amp; MAINTENANCE</b>	3
<b>6. TROUBLE SHOOTING</b>	5
<b>7. WARRANTY</b>	7

Thank you for choosing Dayliff DZ pump. The pump has been manufactured to the highest standards and if operated correctly should give many years of efficient and trouble free service. Careful reading of this instruction manual is therefore extremely important and if you have any queries please refer them to your retailer.

## 1. PUMP SPECIFICATIONS



### Pump

Dayliff DZ self-priming waste water pumps are of semi-open impeller axial flow type designed for pumping water containing high solid levels with particular application for site drainage, sewage and general effluent duties. They are of heavy duty construction and feature a non-return valve on the suction, easy opening cleaning ports and a mechanical seal. Materials are of cast iron throughout.

### Motor

Pumps are close coupled to a non-overloading TEFC motor designed for continuous duty. A remote DOL starter with thermal overload is necessary for motor control.

**Enclosure Class:** IP56

**Insulation Class:** F

### OPERATING CONDITIONS

**Pumped liquid:** Thin, chemically non aggressive liquids with a viscosity of up to  $50\text{mm}^2/\text{s}$  containing suspended solids and particles up to maximum 50mm diameter.


**Maximum Suction Lift:** 6m

**Maximum Liquid Temperature:**  $80^{\circ}\text{C}$

**Max Ambient Temp:**  $40^{\circ}\text{C}$


**Maximum Working Pressure:** 6 Bar

Model	Voltage (V)	Motor		Speed (rpm)	Max Current (A)	Dimensions (mm)					Weight (kgs)
		kW	Hp			Inlet/Outlet	H1	H2	L	W	
<b>DZ 40-110</b>	1 X 240	1.1	1.5	2900	7.2	40	242	168	474	165	57
<b>DZ 50-220</b>	3 X 415	2.2	3.0	2900	4.9	50	321	201	609	210	75
<b>DZ 80-400</b>	3 X 415	4.0	5.4	1450	5.1	80	410	310	735	302	121



## 2. INSTALLATION

- Site in a dry, well ventilated and weather proof location with an ambient temperature less than 40° C. Ensure good ventilation for motor cooling.
- Locate on a solid flat surface ensuring the shaft is in a horizontal position.
- Ensure that the diameter of the suction pipe is at least the size of the pump suction inlet. If the suction depth exceeds 4 meters then a one size larger diameter pipe should be used, though for maximum pump performance suction height should be minimised.
- If there is negative suction (i.e. the pump is above the suction water level) the suction pipe must be slightly angled upwards towards the pump inlet to avoid the formation of air locks. It must also be immersed in water by at least 0.5m to avoid vortexes.
- Ensure that all suction pipe connections are completely airtight or else the pump will not operate.
- The diameter of the delivery pipe must be chosen to suit the flow rate and pressure required at the delivery point though must not be smaller than the pump outlet size. It is also advisable to fit an isolating valve on the delivery outlet. This measure is essential if the delivery pressure exceeds 10m.



- All piping must be supported with suitable brackets to avoid transmitting stress to the pump body. Care must also be taken not to cause damage by over tightening the pipes during fitting.
- Check alignment of the couplings of both pump and motor before use. Misalignment will damage flexible components and cause noisy vibrations.

### 3. ELECTRICAL CONNECTIONS



***The installer is responsible for making electrical connections to the mains supply in compliance with relevant local regulations.***

***Ensure that a professional electrician carries out the electrical connections and that the following guidelines are followed:-***


- All installations must be provided with an isolator to cut off mains power supply and coarse current protection in the form of a fuse or MCB rated at 2-3 times the full load current as given on the pump plate.
- Ensure that the power supply rating complies with the specification on the pump rating plate.
- Electrical connections must be made according to details in the pump junction box cover and effective earthing must be provided according to local regulations.
- Single-phase motors are protected against overloads by a thermal overload fitted in the motor windings. Three phase motors must be fitted with remote starter.
- The direction of pump rotation should be clockwise viewed from drive end.

### 4. PRIMING

When first installed the pump must be filled with water at the priming port. Because this pump is self-priming, subsequent priming after installation is not necessary.



***Serious damage will occur if a pump is not properly primed and runs without water.***



## 5. OPERATION AND MAINTENANCE

Upon starting, carefully check the pump for normal operation including water flow, leakage, vibrations and noise. Abnormal situations should be rectified immediately. Pumps do not require routine maintenance provided the following precautions are taken:-

- Ensure regular flushing of the pump with clean water to prevent build up of waste.
- If the shaft does not run freely, release it using a screwdriver by inserting it in the special slot on the rear of the pump shaft. If this is not sufficient to solve the problem remove the pump body by unscrewing the relevant mounting bolts and clean it thoroughly to remove any encrustation.
- The pump is fitted with two ports in the pump body for cleaning the impeller and pump chamber in case impeller rotation is impeded by solids and waste. These should be opened and the waste removed if pump performance deteriorates.
- If the pump is to remain unused for long periods of time it is advisable to empty it completely, disassemble into spare parts, lubricate with Calcium Base grease or SAE 20W oil and store in a dry place.



***Never carry out work on the pump without having first disconnected from the mains supply.***

# 6. TROUBLE SHOOTING

## PROBLEM

## POSSIBLE CAUSE

## SOLUTION

Pump running but no water is pumped

- Inlet and/or outlet valve not open, pipe or impeller channel clogged
- Wrong direction of motor rotation, motor phase deficiency, low speed
- Air leak in inlet pipe
- Air inside pump chamber
- Not enough water from suction, suction lift too high
- Pipe pressure too high, improper pump model

- Open valve, clean
- Change motor rotation, tighten motor connection
- Check connection, drain air
- Open air bleeding port to release air & repriming
- Check and adjust suction lift
- Put pipe straight, select new pump model

Pump running and there is noise and vibration

- Support foot not stable
- Shaft bent
- Cavitation
- Bearing worn out
- Suction pipe clogged
- Misalignment of pump and motor

- Fix support foot
- Adjust or replace shaft
- Check suction
- Replace bearing
- Clean pipe
- Align accordingly

Not enough delivered water

- Impeller channel and/or inlet pipe clogged, valve not open enough
- Impeller or wear plate worn out

- Clean channel, adjust valve opening
- Replace worn out parts

Shaft power overrating

- Working flow too high
- Suction lift too high
- Pump shaft bent
- Diffuser channel clogged

- Adjust working flow, turn down outlet valve
- Reduce suction lift
- Replace or adjust
- Clean

Motor runs hot

- Working flow too high
- Mechanical resistance in bearings or impeller
- Motor bearing damage
- Voltage too low

- Adjust working flow, turn down outlet valve
- Check pump and bearing
- Replace bearing
- Check and adjust

Water leakage in pump

- Mechanical seal worn
- Crack or hole in casing
- Sealing surface not smooth
- Fasteners loose

- Replace seal
- Replace casing
- Reseal
- Tighten



**PROBLEM****POSSIBLE CAUSE****SOLUTION**

Does not pump adequate volume

Reverse rotation

Correct rotation

Electrical fault

Check electrical connections

Discharge head is high

Recalculate and adjust

High frictional loss

Resize pipe

Air suction

Raise water level or lower pump

Leaking from discharge pipe

Inspect and repair

Clogging of discharge pipe

Remove foreign matter

Foreign matter in suction inlet

Remove foreign matter

Foreign matter clogging pump

Remove foreign matter

Worn out impeller

Replace impeller

Over current

Unbalanced current and voltage

Wait for supply to stabilise

Significant voltage drop

Inspect connections

Motor phase malfunction

Correct rotation

Reverse rotation

Lower head. Excessive volume of water

Replace pump with low head pump

Foreign matter clogging pump

Remove foreign matter

Motor bearing worn or damaged

Replace bearing

## 7. TERMS OF WARRANTY

### i) General Liability

- In lieu of any warranty, condition or liability implied by law, the liability of Davis & Shirliff (hereafter called the Company) in respect of any defect or failure of equipment supplied **is limited to making good by replacement or repair** (at the Company's discretion) defects which under proper use appear therein and arise solely from faulty design, materials or workmanship within a specified period. This period commences **immediately after the equipment has been delivered to the customer** and at its termination all liability ceases. Also the warranty period will be assessed **on the basis of the date that the Company is informed of the failure**.
- This warranty applies solely to equipment supplied and **no claim for consequential damages**, however arising, will be entertained. Also the warranty specifically excludes defects caused by fair wear and tear, the effects of careless handling, lack of maintenance, faulty installation, incompetence on the part of the equipment user, Acts of God or any other cause beyond the Company's reasonable control. Also, any repair or attempt at repair carried out by any other party **invalidates all warranties**.

### ii) Standard Warranty

#### General Terms

If equipment failure occurs in the normal course of service having been competently installed and when operating within its specified duty limits warranty will be provided as follows:-

- **Up to two years - The item will be replaced or repaired at no charge.**
- **Over two years, less than three years - The item will be replaced or repaired at a cost to the customer of 50% of the Davis & Shirliff market price.**

The warranty on equipment supplied or installed by others is conditional upon the defective unit **being promptly returned free to a Davis & Shirliff office** and collected thereafter when repaired. No element of site repair is included in the warranty and any site attendance costs will be payable in full at standard chargeout rates. Also proof of purchase including the purchase invoice must be provided for a warranty claim to be considered.



**DAYLIFF** is a brand of **Davis & Shirtliff**

for enquiries contact

**Davis & Shirtliff, Ltd.**

P.O. Box 41762 - 00100, Nairobi, Kenya

Tel: 6968000/ 0711 079 000

or visit

**[www.dayliff.com](http://www.dayliff.com)**

for details of the nearest branch or stockist