


ITEM NO.	DESCRIPTION	MAN.P/NO.	D&S P/NO.
1	Screw	GB70 M5×43	NSI
3	Bonnet	JHCT079.04.003	NSI
4	Dust cap	JHCT047.01.001	NSI
5	Bonnet	JHCT079.03.003	NSI
6	Pump head	JHCT033.02.058	NSI
7	O-ring	JHCT051.01.030	DDG-7
8	Water deflector	JHCT050.03.030	DDG-8
9	Washer	GB97.1 8	NSI
10	Deflector tray kit	JHCT036.01.019	DDG-10
11	Nut	GB6182 M8	NSI
12	Impeller	JHCT009.04.160	DDG-12
13	Mechanical seal	JHCT061.02.001	DDG-13
14	O-ring	JHCT051.01.137	DDG-14
15	Sealing Plate	JHCT049.01.001	NSI
16	Base	JHCT006.05.003	NSI
17	Hex nut	JHCT076.01.004	NSI
18	Thrower	JHCT059.01.003	NSI
19	Front cover	JHCT025.03.001	NSI
20	Bearing	GB/T276 6201-2Z	BB-6201
21	The key	JHCT081.01.001	NSI
22	Rotor	JHCT023.01.092	NSI
23	Wave washer	JHCT038.01.001	NSI
24	Stator	JHCT022.02.209	NSI
25	Aluminum shell	JHCT024.05.902	NSI
26	Rear cover	JHCT026.02.006	NSI
NSI - Non stock item available on special order only			

ITEM NO.	DESCRIPTION	MAN.P/NO.	D&S P/NO.
27	Fan	J HCT035.01.001	DDG-27
28	Check ring	G B894.1 12	NSI
30	Bolt	G B5780 M5×145	NSI
31	Gasket	J HCT032.01.001	NSI
32	Junction box body	J HCT046.02.003	NSI
33	Bolt	G B818 M4×10	NSI
34	Self-tapping screw	G B845 ST4.2x16	NSI
35	O-ring	J HCT051.01.034	NSI
36	Junction box cover	J HCT046.01.002	NSI
37	15uF capacitor	J HCT084.01.025	DDG-37
38	Self-tapping screw	J HCT078.02.015	NSI
39	Cable press pad	J HCT055.01.003	NSI
40	Sealing block for switch	J HCT032.04.024	NSI
41	Electric cable	J HCT087.03.004	NSI
42	Gasket	J HCT032.03.001	NSI
43	Water proof swicth	J HCT014.05.007	NSI
44	Fan cover	J HCT048.02.006	DDG-44
46	O-ring	J HCT051.01.003	NSI
48	O-ring	J HCT051.01.202	NSI
49	Washer	J HCT038.04.007	NSI
50	Holding down nut for cable	J HCT060.02.003	NSI
51	Hex nut	J HCT076.01.004	NSI
52	O-ring	J HCT051.01.004	DDG-52
53	Bolt	G B9074.8 M4x8	NSI
NSI - Non stock item available on special order only			



REPAIR KIT DDG 1000		
No.	Description	Qty/kit
DDG-12	IMPELLER DDG 1000	1
DDG-13	MECHANICAL SEAL DDG 1000	1
DDG-14	O-RING BASE PLATE DDG 1000	1